


All Floors of Crewkerne

Measuring for carpet or vinyl

In order to work out how much carpet or vinyl you will need you must first measure your room.



To do this, simply measure the room across its longest and widest part. Make sure you measure into any alcoves; it is better to have too much carpet or vinyl than too little! To run your carpet or vinyl into a doorway, measure to where the carpet or vinyl will finish underneath the door. You should then add 10 centimetres (4 inches) onto each measurement. This will allow for cutting, trimming and will help ensure quality fitting. Therefore if your room is 5x3.75 metres you will need carpet or vinyl measuring 5.1 from a 4 metre roll.

Plot your own room and bring your diagram along to us

For accuracy all carpets are ordered and cut to the next largest 10cm (0.1m).

Plot out your room, including any alcoves, on the plan below and bring it with you to **All Floors of Crewkerne**. Once you've chosen your carpet or vinyl we will provide you with a written estimate.

